

TRULINE[®]

The Innovative Hybrid Sheet Piling System

Drawing 110
installation of male end cap

IMPORTANT—PRIOR TO INSTALLATION

It is important to pre-attach the male end cap to the FIRST u-channel prior to driving. Simply slide in place and fasten with coarse thread deck screws on 24" spacing to the u-channel. This will close the open end of the first u-channel and provide a rigid box to drive.

To maintain hook spacing, always construct the wall so that the closed end of the u-channel is the leading edge.

